

Brookville Mining Equipment Corporation
Product Information Bulletin 61 (02-12-04)
Brookville Battery Units
Warnings for Engaging the E-Stop on Personnel Carriers

Purpose:

Operators need to be aware that engaging the E-Stop disconnects all electrical power to the unit, disabling all related functions including but not limited to trammimg, regenerative braking, lights, sanders, horn, etc. Engaging the E-Stop will also apply the emergency/parking brakes.

Action:

Brookville has available a warning label (See Sample Below) to be applied near the E-Stop warning operators of this situation. Contact Brookville Equipment Corporation at (814) 849-2000 to have a warning label (part number T739) shipped to you at no charge. It is further recommended all electrical devices and mechanical systems (such as circuit breakers and brakes) be inspected and if found faulty they be repaired or replaced immediately as needed.

Units Affected:

Brookville manufactured battery personnel carriers.

WARNING
ACTIVATING THE E-STOP DISCONNECTS ALL ELECTRICAL POWER TO THE UNIT, DISABLING ALL RELATED FUNCTIONS SUCH AS TRAMMING, REGENERATIVE BRAKING, LIGHTS, SANDERS, HORN, ETC. ENGAGING THE E-STOP WILL ALSO APPLY THE EMERGENCY/PARKING BRAKE.