Brookville Equipment Corporation Product Information Bulletin 69 (11/30/2011)

All Mining Equipment

Instructions to Remain Seated While the Vehicle is in Motion

Purpose:

To reinforce the necessity to remain properly seated while the vehicle is in motion.

Action:

Before tramming, the operator and all passengers are to be properly seated and are to remain properly seated while the vehicle is in motion. All persons are to keep their head, body, and extremities within the interior perimeter of the operator/passenger compartment at all times.

The vehicle may also be equipped with such items as overhead sliding covers or doors, safety chains, seat belts, or other similar restraints. These items are to be fully closed and/or fastened before tramming and must remain fully closed and/or fastened at all times while the vehicle is in motion.

Failure to follow these operating instructions may result in death or serious injury.

Brookville Equipment has available a warning plate (see sample below) to be applied in all operator and passenger compartments. Contact Brookville Equipment Corporation at (814)849-2000 to have a warning plate (p/n T1628) shipped to you at no charge using the attached Order Form. When you have received and installed the new warning plate please return the attached Verification Form for our records.

Units to Which Product Bulletin is Applicable:

ΑII



PRODUCT INFORMATION BULLETIN 69

WARNING PLATE ORDER FORM

Please complete this form and send to:

Brookville Equipment Corp.
ATTN:
175 Evans St
Brookville, PA 15825
Fax:
Email:

Date:		 	
Company:	 	 	
Mine Location:			
Ordered by:			
Ship to:			
·			
Phone:			

ITEM	DESCRIPTION	QTY.	FOR UNITS
T1628	TAG, DANGER		

PRODUCT INFORMATION BULLETIN 69

WARNING PLATE INSTALLATION VERIFICATION FORM

Please complete and return this verification form once you have installed the T1628 Warning Plate to the Brookville unit(s) at your mine. Please return form to:

Brookville Equipment Corp.
ATTN:
175 Evans St
Brookville, PA 15825
Fax:
Email:

Name:

Signature:				
Company: Mine Location: Address:				
Phone:				
() Our company has added the Warning Tag to our following units:				
UNIT SERIAL NO.	UNIT MODEL NO.	DATE INSTALLED	LOCATION (BRIEF DESCRIPTION OF WHERE PLATES WERE INSTALLED ON UNIT)	

Your cooperation in updating your unit(s) with this Warning Tag is greatly appreciated.